

BMW K100RS/K1100RS Parabellum Windscreen Installation Instructions



This item can be found at <http://www.parabellum.com/>. (Replacement windshields → BMW → Page 3)

1. Remove stock windscreen by removing the plastic "ears" behind the left and right supports of the main fairing and then removing the machine screws that hold the windscreen in place.
2. Swing all four aluminum brackets on the Parabellum windscreen base out of the way and place the base into the RS fairing "ears" from the front side.
3. Swing all four brackets into position, reinstall stock windscreen machine screws and stock black "ear" trim.
4. Install Parabellum windscreen onto base using nylon screws, washers and nuts. (DO NOT OVERTIGHTEN or you will crack the windscreen.)

Original hand-written instructions from Parabellum:

Parabellum Ltd.

82 Spring Road • Dahlonega, GA 30533 • (706) 864-8051 • FAX (706) 864-5770

K100RS WINDSHIELD SYSTEM INSTRUCTIONS K1100RS

1. REMOVE STOCK WINDSHIELD BY REMOVING BLACK PLASTIC TRIM PIECES ON BACKSIDE OF FAIRWE "EARS" THEN UNSCREW WS SCREWS.
2. SWW ALL 4 ALUMINUM BRACKETS ON PARABELLUM BASE OUT OF THE WAY AND PLACE BASE INTO RS FAIRWE EARS FROM THE FRONT SIDE.
3. SWW ALL 4 BRACKETS BACK INTO POSITION, AND REINSTALL STOCK WS SCREWS, STOCK BLACK TRIM.
4. INSTALL PARABELLUM WS TO PARABELLUM BASE USING NYLON SCREWS, WASHERS, AND NUTS. (DO NOT OVERTIGHTEN!)